


MERCANA

ART | FURNITURE | LIGHTING | DECOR



item 70917

name Tosha pendant


wattage 100 W

voltage 120 V


socket E26

size 24X24X13.5 in


1




2



3



4



Different by design.
www.mercana.com



3250 189th Street
Surrey BC, Canada
V3Z 0L5


e: artinfo@mercana.com
p: 800.461.1666
f: 888.919.1666

CAUTION:

Before starting, turn off power at main circuit panel.

ATTENTION:

coupez l'alimentation avant de procéder à l'installation



WARNING:

1. The installation work should only be performed by qualified electricians.
2. Ensure the fixture is disconnected from main power before installation.
3. Make sure the fixture is securely supported.
4. Indoor use only

IMPORTANT:

1. Please wear gloves to install.
2. Ensure there is no moisture in the ceiling before installing fixture.
3. Ensure that the electrical supply complies with the type stated on rating label.
4. Used lighting source shall be of suitable model and wattage
5. Avoid touching the shade and bulb when the lamp is working
6. Please cut off power and let the bulb and shade cool down before replacing the bulb & use dry cloth to clean the lamp.
7. Please install according to above steps.
8. If the external flexible cable or cord of this fixture is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.