


MOE'S

Assembly Instructions



Rosemary Kitchen

EF-1052-04



THANK YOU FOR YOUR PURCHASE!

PARTS AND HARDWARE


1 Top X 1	
	
2 Base X 1	
	
A Bolt x 8	B Flat Washer x 8
	
C Spring Washer x 8	D Hex Key x 1
	
E Spring Washer x4	
	

Notes


Thank you for purchasing this quality product!
Be sure to check all packing material carefully
for small part that may have come loose inside
the carton during shipping.

CAUTION: The item is heavy, assembly
should be performed by two people.



Step 1



Step 2



PARTS AND HARDWARE


1 Top X 1	
	
2 Base X 1	
	
A Bolt x 8	B Flat Washer x 8
	
C Spring Washer x 8	D Hex Key x 1
	
E Spring Washer x4	
	

Notes

Thank you for purchasing this quality product!
Be sure to check all packing material carefully
for small part that may have come loose inside
the carton during shipping.

CAUTION: The item is heavy, assembly
should be performed by two people.

Step 3



Adjustable Levelers