
ASSEMBLY INSTRUCTIONS

11004 / 11005 / 11006 / 11007 / 11008 / 11009 - C


meridian furniture



+ Do Not Use Power Tools



+ Suggested Adults



NOTE: For questions about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455.

1 Read instructions cover to cover.
2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if the parts arrived damaged.


Do not assemble if Hardware parts are missing.

2 IMPORTANT ASSEMBLY INFORMATION


Assembly Step lf loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Parts Included

① Leg frame (1 pc)




② Seat frame (1 pc)



+ Parts Included


A. Bolt
Ø8x45mm (4 pcs)




B. Spring Washer
Ø8xØ13mm (4 pcs)



C. Flat Washer
Ø8xØ19mm (4 pcs)




D. Allen Key (1 pc)




ASSEMBLY INSTRUCTIONS

11004 / 11005 / 11006 / 11007 / 11008 / 11009 - C

①



②



NOTE: For questions about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455.

www.MeridianFurnitureUSA.com | support@meridianfurnitureusa.com