
ASSEMBLY INSTRUCTIONS
316/317-Sideboard

meridian furniture



+Do Not Use Power Tools



+Suggested Adults




NOTE: For questions about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455.

1 Read instructions cover to cover.
2 Save all packaging until assembly is completed

+Parts Included

① Sideboard Body (1 pc)



② Leg (5 pcs)



1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:
Part① - Sideboard Body
Part② - Leg

Do not assemble if any of the following Hardware parts are missing:
Part A - Flat Washer
Part B - Spring Washer
Part C - Allen Bolt
Part D - Allen Key

2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+Hardware Included

A Flat Washer (20 pcs)



B Spring Washer (20 pcs)



C Allen Bolt (20 pcs)



D Allen Key (1 pc)




ASSEMBLY INSTRUCTIONS

316/317-64"W×18"D×31"H

meridian furniture

1



NOTE: For questions about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455.
www.MeridianFurnitureUSA.com | support@meridianfurnitureusa.com