
ASSEMBLY INSTRUCTIONS

#537/#538/#539 DINING CHAIR

meridian furniture



+ Do Not Use Power Tools



+ Suggested Adults




NOTE: For questions about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455.

1 Read instructions cover to cover.

2 Save all packaging until assembly is completed.

+ Parts Included

① 

X1

② 

X1

③

④

⑤

⑥

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

Part #-①

Part #-②

Do not assemble if any of the following Hardware parts are missing:


Part #-A

Part #-B


2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.


+ Hardware Included

A 

Bolt (M6×35) 4pcs

B 

4pcs
Flat Washer (Ø16×Ø6)

C 

Allen Wrench (4mm) 1pc

D

E


F

ASSEMBLY INSTRUCTIONS


#537/#538/#539 DINING CHAIR

meridian furniture

1



2



NOTE: For questions about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455.